FLASHFLARE

ROADSIDE ELECTRONIC FLARE KIT

USER MANUAL

[This manual contains important information regarding the operation and warranty of this product. Please read carefully before using and store for future reference.]

Table of Contents

Specifications ——— 2

Product Features ——— 3

Operations ——— 4

Troubleshooting / Warnings ——— 7

Warranty ——— 8

Specifications

4 Lighting Sequences :

1 : Rotate Continuously

2 : Pulsating

3 : Full Rotate with pause

4 : Continuous Blinking

Power Source :

(2) C-Cell Batteries

Battery Life :

Approximately 9 - 12 hours

Product Features

- Top LED lights for helicopter duty
- Shock-resistant polycarbonate body
- 360° viewing angle
- Visible during day and night
- Variable lighting sequences
- High intensity LED lights
- Bright orange rings with UV stabilizers
- Soft handle grips
- Reflective coating rings
- Elevated and stackable base for uneven roads
- Compact design
- All-weather resistant

Operations


Helicopter/Air Duty
LED Lights
High Intensity
LED Lights
On/Off Power Button
(Lighting Sequence Selector)
Soft Grip Handle
Reflective Rings
Shock Resistant
Polycarbonate Body
Magnetic Base
Elevated Base
Compact/Stackable Base

Battery Installation

1. Simply unscrew the Flash Flare counter-clockwise in the middle of the stick and install the two c-celled batteries according to the proper polarity.

2. Screw the Flash Flare back together clockwise.



Powering and Changing Lighting Sequences on the Flash Flare

1. After installing batteries correctly, press the power button. The first lighting sequence will begin. (See page 2 for lighting sequences)

2. Press the power button twice for the second lighting sequence.

3. Press the power button three times for the third light sequence.

4. Press the power button a fourth time for the final lighting sequence.

5. Press the flare a fifth time to power off.



Troubleshooting

No Power

1. Replace the batteries and power on the Flash Flare.

2. Check that the Flash Flare is securely tightened for full battery contact.

Warnings

1. Dispose of batteries properly. Do not dispose this battery in fire. This may result in an explosion.

2. DO NOT expose this unit to extremely high temperatures.

3. DO NOT submerge in any liquids.

Warranty

The warranty period is for ONE year from the time of purchase, and only covers manufacturer defects. This warranty does NOT cover damage due to abuse, unauthorized repair, submerging in any liquid, and neglect. To obtain warranty service, you may return the defective product to the authorized Lorest Holding LLC., retailer or distributor, with proof of purchase, and receive a replacement unit. Please check with the retailer or distributor for their return policies and procedures. This warranty may give you other legal rights, which vary from state to state.

Manufactured by:
Lorest Holding LLC.
730 New Hampshire Street, Ste. 205
Lawrence, KS 66044
www.lorest.com

www.lorest.com